

MANDO BLASTER

ASSEMBLY DIAGRAMS








BODY ASSEMBLY

- 1X - MAG PLATE
- 1X - MAG DISK
- 1X - MAG SCREW
- 1X - MAG NUT
- 1X - CLEANING ROD
- 1X - CLEANING ROD END
- 1X - CLEANING ROD CLAMP
- 1X - SLOT GREEBLE
- 1X - POMMEL
- 1X - POMMEL SCREW (8-32 X 7/16)
- 1X - SAFETY
- 2X - SAFETY PIN (3/32 X 3/16)
- 1X - 8-32 X 1/4 LOW HEAD



BREECH ASSEMBLY

- BREECH RAIL
- BREECH PLATE
- BREECH PLATE PIN (3/32 X 3/16)
- JMB SCREW LEVER
- JMB SCREW



BARREL ASSEMBLY

- 1X) BARREL
- 1X) BARREL COVER
- 1X) BARREL SCREW (10-32 X 1 1/2 BUTTONHEAD)
- 1X) FLASH HIDER
- 1X) FLASH HIDER SCREW (10-32 X 1/2 FLAT HEAD)
- 1X) FRONT SIGHT
- 1X) BARREL BLOCK
- 1X) BARREL BLOCK PIN (1/16 X 1/4)
- 2X) BARREL TAB
- 1X) BARREL ROD
- 1X) ROD SCREW (8-32 X 1/8 BUTTON HEAD)



TRIGGER ASSEMBLY

- 1X - TRIGGER
- 1X - KNUCKLE
- 1X - ROCKER
- 1X - HAMMER
- 1X - HAMMER PIN (3/16 X 7/16)
- 1X - FIRING PIN (5/32 X 1/4)
- 3X - ASSEMBLY PIN (3/32 X 7/16)
- 1X - KNUCKLE SPRING (SMALL SPRING)
- 1X - ROCKER SPRING (LARGE SPRING)
- 2X - LEAF SPRING
- 1X - TRIGGER COVER
- 1X - SMALL BUTTON
- 1X - LARGE BUTTON
- 1X - COVER SCREW (8-32 X 1/2 SLOTTED PAN HEAD)

HAMMER

FIRING PIN

ASSEMBLY PINS

1X - TRIGGER

1X - KNUCKLE

1X - ROCKER

1X - HAMMER

1X - HAMMER PIN (3/16 X 7/16)

1X - FIRING PIN (5/32 X 1/4)

3X - ASSEMBLY PIN (3/32 X 7/16)

1X - KNUCKLE SPRING (SMALL SPRING)

1X - ROCKER SPRING (LARGE SPRING)

2X - LEAF SPRING

HAMMER PIN

1X - TRIGGER COVER

1X - SMALL BUTTON

1X - LARGE BUTTON

1X - COVER SCREW (8-32 X 1/2 SLOTTED PAN HEAD)



KNUCKLE SPRING

ROCKER SPRING

ROCKER

TRIGGER

KNUCKLE

TRIGGER COVER

COVER SCREW

LARGE BUTTON

SMALL BUTTON

LEAF SPRINGS


15

14

14

REAR SIGHT ASSEMBLY

- 11X)SIGHT BODY
- 1X)SIGHT BACK
- 2X) SIGHT BUTTON
- 1X)REAR SIGHT LEAF
- 2X)REAR SIGHT PIN (1/16 X ¼)



GRIPS

